

EZ AIM® SPLASH NON-ADHESIVE SILHOUETTE 12 X18 PAPER TARGETS - ALLEN CO INC EZ AIM SPLASH NON-ADHSV SILHOUETTE 12"X18" PPR TARGET 5/PACK

ALLEN CO INC. EZ AIM® SPLASH NON-ADHESIVE SILHOUETTE 12"X18" PAPER TARGETS The Allen EZ Aim® Splash Reactive Shooting Targets show you exactly where every shot hits without walking downrange. Bright chartreuse splashes appear instantly around each bullet hole, so you can see your groupings and adjust your aim from the shooting line. No more squinting through binoculars or wasting time checking targets between rounds. These 12 inch by 18 inch silhouette targets work great for pistol practice, rifle sighting, and improving your shooting accuracy at indoor ranges or outdoor shooting spots. The high-contrast design stays visible at distances up to 100 yards, making them perfect for long-range rifle practice and handgun training. Whether you're practicing for deer hunting season, working on your groupings, or running drills at the range, you'll see immediate results with every shot. Each pack includes five full-size targets, giving you plenty of shooting sessions before needing to restock. The human silhouette shape helps with realistic practice for hunting scenarios and defensive training. These reactive targets work with all calibers and firearm types, from .22 rifles to centerfire handguns.

FEATURES SEE EVERY SHOT INSTANTLY: Bright chartreuse splashes appear around each bullet hole so you can track your accuracy and adjust your aim without walking downrange or using binoculars. **HIGH-CONTRAST VISIBILITY:** White impact zones with bright splashes stay visible from the shooting line at distances up to 100 yards for pistol shooting, rifle practice, and long-range training. **LIFE-SIZE SILHOUETTE SHAPE:** 12 inch by 18 inch human outline provides realistic practice for deer hunting preparation, defensive drills, and practical shooting scenarios beyond basic bullseye targets. **WORKS FOR ALL FIREARMS:** Compatible with .22 rifles, centerfire handguns, shotguns, and hunting rifles for versatile use during range practice and pre-season sighting sessions. **INCLUDES 5 FULL-SIZE TARGETS:** Multiple targets give you several shooting sessions for working on accuracy, testing different loads, and practicing before hunting season without constant reordering. **SPECS Material:** Paper Targets Size: 12 Inch x 18 Inch

NO IMAGE
AVAILABLE

Attributes

- Name: ALLEN CO INC EZ AIM SPLASH NON-ADHSV SILHOUETTE 12"X18" PPR TARGET 5/PACK
- Manufacturer: ALLEN CO INC
- Product no.: 430119939
- Mfr. No.: 15330
- Style: Silhouette
- Target Size/Type: 12 x 18
- Type: Papers
- Quantity: 5
- Delivery weight: 0.227kg
- Shipping height: 318mm
- Shipping width: 6mm
- Shipping length: 489mm
- UPC: 026509048107

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: EZ AIM® Splash NonAdhesive Silhouette 12 x 18 Paper Targets Safety Instruction Guide](#)
- [Italiano: Guida di Sicurezza per l'Utilizzo dei Bersagli EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 X 18 PAPER TARGETS](#)
- [Norsk: Bruksanvisning for sikkerhet EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 X 18 PAPIRMÅL](#)

EZ AIM® Splash NonAdhesive Silhouette 12 x 18 Paper Targets Safety Instruction Guide

Introduction

Thank you for choosing the EZ AIM® Splash NonAdhesive Silhouette Paper Targets by Allen Co Inc. This product is designed to enhance your shooting practice by providing clear visual feedback on your accuracy. To ensure safe and effective use of these targets, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always handle firearms responsibly and in accordance with local laws and regulations.
- Ensure that all shooting activities are conducted in a safe environment, such as designated shooting ranges.
- Use appropriate eye and ear protection when shooting.
- Keep the shooting area clear of unauthorized individuals, especially children and pets.
- Regularly inspect targets for any signs of damage before use.
- Dispose of used targets properly to avoid environmental hazards.

Specific Safety Precautions for Use

- Do not use targets that are damaged or have been previously shot.
- Ensure that the target is securely positioned and will not fall or move during use.
- Maintain a safe distance from the target based on the type of firearm being used.
- Be aware of your surroundings and ensure that the area behind the target is safe and free of obstructions.
- Avoid using targets in adverse weather conditions that may affect visibility or safety.

Instructions for Installation and Usage

1. Target Setup:

- Choose a suitable location for your target, ensuring it is within a safe shooting range.
- Use a target stand or securely attach the target to a solid backing to prevent it from falling.
- Ensure the target is at a reasonable height and distance for your shooting practice.

2. Shooting:

- Stand at the designated shooting line, ensuring all safety precautions are observed.
- Aim carefully at the target and take your shot.
- After each shot, observe the bright chartreuse splashes that indicate where the bullet has struck.

3. PostShooting:

- After completing your shooting session, carefully collect all used targets for proper disposal.
- Inspect the shooting area for any remaining debris or hazards.

Disposal Instructions

- Used paper targets should be disposed of in accordance with local waste disposal regulations.
- Avoid leaving used targets in shooting areas to prevent littering and environmental impact.
- If the targets are made of materials that are recyclable, please recycle them appropriately.

Contact Information for Further Support

For any safety inquiries or concerns regarding the EZ AIM® Splash NonAdhesive Silhouette Paper Targets, please refer to the contact information provided on the packaging or your point of purchase.

By following these safety instructions, you can ensure a safe and enjoyable shooting experience with the EZ AIM® Splash NonAdhesive Silhouette Paper Targets. Always prioritize safety and responsible use while practicing your shooting skills.

Guida di Sicurezza per l'Utilizzo dei Bersagli EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 X 18 PAPER TARGETS

Introduzione

Grazie per aver scelto i bersagli EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 x 18 PAPER TARGETS di ALLEN CO INC. Questa guida di sicurezza fornisce importanti informazioni per garantire un utilizzo sicuro ed efficace del prodotto, in conformità con le normative europee sulla sicurezza dei prodotti.

Linee Guida Generali di Sicurezza

- Assicurati che il prodotto sia utilizzato solo per scopi previsti e in conformità con le istruzioni fornite.
- Controlla regolarmente il prodotto per eventuali segni di usura o danni.
- Non utilizzare il prodotto se è danneggiato o non conforme alle specifiche.
- Conserva il prodotto in un luogo asciutto e sicuro, lontano dalla portata di bambini e animali domestici.
- Segnala eventuali prodotti non sicuri o incidenti alle autorità competenti.

Precauzioni di Sicurezza Specifiche per l'Utilizzo

- Utilizza i bersagli EZ AIM® solo in aree designate per il tiro e segui tutte le normative locali riguardanti il tiro.
- Assicurati di avere una buona visibilità del bersaglio e dell'area circostante prima di iniziare a tirare.
- Indossa sempre occhiali protettivi e, se necessario, protezioni per le orecchie durante l'uso.
- Non tirare mai verso persone, animali o oggetti non autorizzati.
- Controlla che il bersaglio sia fissato saldamente e non possa cadere o muoversi durante il tiro.

Istruzioni per l'Installazione e l'Uso

1. Preparazione del Bersaglio:

- Rimuovi il bersaglio dalla confezione.
- Assicurati che il bersaglio sia privo di pieghe o danni.

2. Posizionamento:

- Fissa il bersaglio su una superficie piana e stabile, come un supporto per bersagli o una parete di tiro.
- Assicurati che il bersaglio sia ben visibile e facilmente accessibile.

3. Utilizzo:

- Inizia a tirare seguendo le tecniche di tiro corrette.
- Monitora i colpi e verifica i risultati visivi forniti dagli spruzzi di color chartreuse.
- Regola il tuo tiro in base ai risultati ottenuti.

4. Dopo l'Uso:

- Rimuovi il bersaglio dal supporto e smaltiscilo correttamente.
- Controlla l'area di tiro per eventuali detriti o materiali pericolosi.

Istruzioni per lo Smaltimento

- Smaltisci i bersagli EZ AIM® in conformità con le normative locali sullo smaltimento dei rifiuti.
- Se possibile, ricicla il materiale di carta.
- Non abbandonare i bersagli in aree pubbliche o in natura.

Informazioni di Contatto per Ulteriore Supporto

Per domande relative alla sicurezza del prodotto o per segnalare eventuali problemi, contatta il tuo rivenditore o il produttore. Assicurati di avere a disposizione le informazioni sul prodotto e il numero di serie, se disponibile.

Seguendo queste linee guida, puoi garantire un'esperienza di tiro sicura e soddisfacente con i bersagli EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 x 18 PAPER TARGETS.

Bruksanvisning for sikkerhet EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 X 18 PAPIRMÅL

Introduksjon

Velkommen til bruksanvisningen for EZ AIM® SPLASH NONADHESIVE SILHOUETTE 12 X 18 PAPIRMÅL. Dette dokumentet gir viktig informasjon om sikker bruk av produktet, i samsvar med EU's generelle produkt sikkerhetsforordning (GPSR). Vennligst les alle instruksjoner og retningslinjer nøye for å sikre en trygg og effektiv opplevelse.

Generelle sikkerhetsretningslinjer

- Produktet er designet for å være trygt å bruke, men det er viktig å følge disse retningslinjene:
 - Bruk alltid produktet i henhold til produsentens instruksjoner.
 - Hold produktet utilgjengelig for barn og sårbare grupper.
 - Kontroller produktet for skader før bruk. Hvis det er skadet, må det ikke brukes.
 - Vær oppmerksom på omgivelsene dine når du bruker produktet, og sørg for at det ikke er noen hindringer eller farer i nærheten.
 - Rapportér eventuelle ulykker eller skader til relevante myndigheter.

Spesifikke sikkerhetstiltak for bruk

- Følgende sikkerhetstiltak må følges for å unngå potensielle farer:
 - Sørg for at målområdet er klart og at det ikke er personer eller dyr i nærheten.
 - Bruk alltid riktig skytevåpen og ammunisjon som er kompatibel med produktet.
 - Unngå å bruke produktet under ugunstige værforhold, som sterk vind eller regn, som kan påvirke siktingen.
 - Ikke berør eller håndter skytevåpen eller ammunisjon mens du er i nærheten av målet.
 - Bruk alltid passende beskyttelsesutstyr, som øre og øyevern, når du bruker produktet.

Instruksjoner for installasjon og bruk

- Følg disse instruksjonene for korrekt installasjon og bruk av EZ AIM® SPLASH NONADHESIVE SILHOUETTE PAPIRMÅL:
 - Velg et passende sted for å henge opp målet, som er trygt og har god synlighet.
 - Fest målet på en vertikal overflate, som en målvegg eller en annen stabil støtte, ved hjelp av ikkeklebende metoder som klemmer eller nåler.
 - Sørg for at målet er i øyehøyde for bedre sikte.
 - Når du er klar til å skyte, ta plass på en sikker avstand fra målet og kontroller at området er klart.
 - Etter at du har skutt, sjekk målet for å se sprutene og vurder nøyaktigheten din.

Avfallsinstruksjoner

- Når du er ferdig med å bruke målet, må det kastes på en ansvarlig måte:
 - Papirmål kan kastes i vanlig papiravfall.
 - Sørg for at eventuelle rester av produktet ikke forurensrer miljøet.
 - Følg lokale retningslinjer for avfallshåndtering.

Kontaktinformasjon for videre støtte

- For spørsmål om sikkerhet eller produktinformasjon, vennligst kontakt produsenten direkte. Det er viktig å ha informasjon fra en pålitelig kilde for å sikre trygg bruk av produktet.

Vi håper du får en trygg og produktiv opplevelse med EZ AIM® SPLASH NONADHESIVE SILHOUETTE PAPIRMÅL.