

EZ AIM® FUN GET THE GAME ON PAPER SHOOTING TARGETS - ALLEN CO INC EZ AIM FUN GET THE GAME ON 12"X18" PPR SHOOTING TARGETS 8/PK

ALLEN CO INC. EZ AIM® FUN GET THE GAME ON PAPER SHOOTING TARGETS
The EZ Aim® Fun Get Your Game On Targets are a part of the EZ Aim® Fun collection, designed to make your shooting experience more fun. Made with an abundance of color and designs, these targets naturally bring a smile to target practice. Not only do they grade high in performance, but they grade higher in fun! The Get Your Game On shooting targets provide an assortment of 4 different target games (2-targets per style). The Score the Core Targets (2) is a fun take on the classic center-of-mass target. The House of Cards Targets (2) become whatever card game the shooter chooses, cards displayed face-up. Doug's Arcade Targets (2) gives shooters multiple targets for extensive target practice. Tic-Tac-Bang Targets (2) challenges shooters to a friendly game of Tic-Tac-Toe. Provided in the pack are 8-shooting targets (2 per style), each measuring 12-inches wide x 18-inches high. FEATURES FUN TRAINING TARGETS: Assorted pack of targets made with an abundance of colors & designs to make your shooting experience more fun. ASSORTED TARGET PACK: Pack contains an assorted pack of 8-shooting targets - House of Cards Targets (2), Tic-Tac Bang Targets (2), Score the Core Targets (2), & Doug's Arcade Targets (2). COMPATIBILITY: Target can be used with a wide range of weapons including pistols, handguns, shotguns, airsoft guns, BB guns, and pellet guns. INDOOR / OUTDOOR USE: Great for competition, shooting games, and casual shooting practice; mount on a wall or use as a free-standing hanging bracket. HOUSE OF CARDS TARGETS: Convert your favorite card game into target practice. TIC-TAC-BAG: Choose "X's" or "O's" & get three shots in a row. SCORE THE CORE: Designed with center-of-mass shooting game. DOUG'S ARCADE: Choose any game with the variety of targets included. PAPER SHOOTING TARGET: Pack includes 8-shooting targets (2 per style), each measuring 12-inches wide x 18-inches high. SPECS Material: Paper Targets Size: 12 Inch x 18 Inch

NO IMAGE
AVAILABLE

Attributes

- Name: ALLEN CO INC EZ AIM FUN GET THE GAME ON 12"X18" PPR SHOOTING TARGETS 8/PK
- Manufacturer: ALLEN CO INC
- Product no.: 430119940
- Mfr. No.: 15642
- Style: Papers
- Target Size/Type: 12 x 18
- Type: Papers
- Quantity: 8
- Delivery weight: 0.177kg
- Shipping height: 464mm
- Shipping width: 305mm
- Shipping length: 3mm
- UPC: 026509067948

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for EZ AIM® FUN GET THE GAME ON PAPER SHOOTING TARGETS](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per i Bersagli EZ AIM® FUN GET THE GAME ON](#)
- [Norsk: Sikkerhetsinstruksjoner for EZ AIM® FUN GET THE GAME ON PAPIR SKYTEMÅL](#)

Safety Instruction Guide for EZ AIM® FUN GET THE GAME ON PAPER SHOOTING TARGETS

Introduction

Thank you for choosing the EZ AIM® Fun Get Your Game On Paper Shooting Targets. This guide provides important safety instructions and information to ensure a safe and enjoyable shooting experience. Please read this guide carefully before using the product.

General Safety Guidelines

- Always handle shooting targets responsibly and in accordance with local laws and regulations.
- Ensure that all users are aware of the safety guidelines and instructions provided in this document.
- Keep shooting targets out of reach of young children and vulnerable individuals.
- Regularly inspect your shooting area for hazards, such as obstacles or unsafe conditions.
- Use appropriate protective gear, such as eye and ear protection, when participating in shooting activities.
- Always supervise minors when using shooting targets.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for children under the age of 12. Adult supervision is required for users under 18.
- **Shooting Area:** Use the targets in a designated shooting area that is safe and free from bystanders. Ensure the area is clear of any obstructions.
- **Target Compatibility:** The targets are compatible with a variety of shooting devices, including pistols, handguns, shotguns, airsoft guns, BB guns, and pellet guns. Ensure you are using the appropriate type of gun for the targets.
- **Environmental Conditions:** Avoid using the targets in wet or windy conditions to ensure they remain stable and intact.
- **Target Disposal:** Dispose of used targets responsibly. Do not leave them in public areas or natural environments.

Instructions for Installation and Usage

- **Installation:**
 - The targets can be mounted on a wall or used with a freestanding hanging bracket.
 - Ensure that the mounting area is secure and stable to prevent the targets from falling during use.
- **Usage:**
 - Select the target style you wish to use (e.g., House of Cards, TicTacBang, Score the Core, Doug's Arcade).
 - Position the target at a safe distance according to the type of shooting device being used.
 - Ensure all participants are positioned behind a safe line of fire.
 - After shooting, evaluate the targets for damage and replace them as necessary to maintain a safe shooting environment.

Disposal Instructions

- Dispose of used paper shooting targets in accordance with local waste disposal regulations.
- Recycle the targets if applicable, ensuring they are placed in the appropriate recycling bin if made from recyclable materials.

Contact Information for Further Support

For any safety inquiries or further information regarding the EZ AIM® Fun Get Your Game On Paper Shooting Targets, please reach out to the manufacturer or an appropriate consumer safety authority in your region.

By following these safety guidelines and instructions, you can enjoy a safe and fun shooting experience with the EZ AIM® Fun Get Your Game On Paper Shooting Targets. Always prioritize safety and responsible usage in all shooting activities.

Guida alle Istruzioni di Sicurezza per i Bersagli EZ AIM® FUN GET THE GAME ON

Introduzione

Grazie per aver scelto i bersagli EZ AIM® FUN GET THE GAME ON di ALLEN CO INC. Questa guida fornisce informazioni importanti sulla sicurezza, l'uso e lo smaltimento dei bersagli. È fondamentale seguire queste istruzioni per garantire un'esperienza di tiro sicura e divertente.

Linee Guida Generali di Sicurezza

- Assicurati di utilizzare i bersagli in un'area sicura e controllata, lontano da persone e animali.
- Controlla i bersagli per eventuali danni prima dell'uso. Non utilizzare bersagli danneggiati.
- Utilizza sempre l'equipaggiamento di protezione personale, come occhiali protettivi e tappi per le orecchie, durante la pratica di tiro.
- Segui sempre le leggi e i regolamenti locali riguardanti l'uso delle armi e il tiro.

Precauzioni di Sicurezza Specifiche per l'Uso

- I bersagli sono progettati per l'uso con una vasta gamma di armi, tra cui pistole, fucili e airsoft. Assicurati che l'arma utilizzata sia idonea ai bersagli.
- Non utilizzare i bersagli in spazi ristretti o in aree non designate per il tiro.
- Non colpire mai i bersagli con munizioni non appropriate o armi non conformi.
- I bersagli non sono adatti per l'uso da parte di bambini senza supervisione di un adulto.
- In caso di malfunzionamento dell'arma o di un incidente, interrompi immediatamente l'uso e cerca assistenza.

Istruzioni per l'Installazione e l'Uso

- Posizionare i bersagli su una superficie piana o montare i bersagli su una parete sicura.
- Per l'uso come supporto appeso autonomo, assicurati che i bersagli siano ben fissati e non possano cadere.
- Scegli il bersaglio desiderato dal pacco assortito e assicurati che sia ben visibile da una distanza adeguata.
- Segui le istruzioni specifiche per ciascun tipo di bersaglio:
 - **House of Cards Targets:** Utilizza per trasformare il tuo gioco di carte preferito in una pratica di tiro.
 - **TicTacBang:** Scegli "X" o "O" e cerca di ottenere tre colpi di fila.
 - **Score the Core:** Progettato per il tiro al centro della massa.
 - **Doug's Arcade:** Scegli un gioco dalla varietà di bersagli inclusi.

Istruzioni per lo Smaltimento

- I bersagli EZ AIM® FUN GET THE GAME ON sono realizzati in carta. Quando non sono più utilizzabili, smaltiscili in modo responsabile.
- Se possibile, ricicla i bersagli secondo le normative locali sul riciclaggio della carta.
- Non bruciare i bersagli, in quanto potrebbero emettere sostanze nocive.

Informazioni di Contatto per Ulteriore Supporto

Per domande sulla sicurezza dei prodotti o per segnalare prodotti non sicuri, contatta il tuo rivenditore o cerca informazioni sul sito web ufficiale di ALLEN CO INC. Assicurati di controllare gli aggiornamenti delle notifiche di richiamo attraverso la piattaforma Safety Gate dell'Unione Europea.

Seguire queste istruzioni contribuirà a garantire un'esperienza di tiro sicura e divertente con i bersagli EZ AIM®
FUN GET THE GAME ON. Buon divertimento e tiro sicuro!

Sikkerhetsinstruksjoner for EZ AIM® FUN GET THE GAME ON PAPIR SKYTEMÅL

Introduksjon

Takk for at du valgte EZ AIM® FUN GET THE GAME ON PAPIR SKYTEMÅL fra ALLEN CO INC. Disse papirskytemålene er designet for å forbedre din skyteopplevelse. For å sikre trygg og effektiv bruk, vennligst les og følg disse sikkerhetsinstruksjonene nøye.

Generelle sikkerhetsretningslinjer

- Sørg for at alle brukere av produktene er kjent med sikkerhetsprosedyrer for skyting.
- Oppbevar alltid produkter utilgjengelig for barn.
- Bruk alltid beskyttelsesutstyr som øye og hørselsvern når du bruker skytemålene.
- Kontroller at området der du skyter er sikkert og fritt for hindringer.
- Følg alltid lokale lover og forskrifter angående skyting.

Spesifikke sikkerhetsforholdsregler for bruk

- **Alder:** Dette produktet er ikke ment for bruk av barn uten tilsyn av en voksen.
- **Våpenkompatibilitet:** Bruk kun mål med godkjente våpen som nevnt i produktbeskrivelsen.
- **Innendørs/Utendørs bruk:** Sørg for at målene er festet sikkert hvis de brukes innendørs.
- **Konkurranser og skytespill:** Sørg for at alle deltakere er klar over sikkerhetsprosedyrer før konkurransen begynner.

Instruksjoner for installasjon og bruk

- **Montering av mål:**
 - Velg en passende overflate for montering (vegg, stand etc.).
 - Bruk tape eller stifter for å feste målene på plass.
- **Bruk av mål:**
 - Plasser målene i en sikker avstand fra alle personer og eiendom.
 - Bruk et passende våpen og ammunisjon i henhold til produsentens anbefalinger.
 - Følg alle sikkerhetsprosedyrer under skyting.

Avfallsinstruksjoner

- Når papirskytemålene er brukt, kan de kastes i vanlig papiravfall.
- Sørg for at de ikke inneholder noen farlige materialer før de kastes.
- Resirkuler om mulig.

Kontaktinformasjon for videre støtte

For spørsmål eller bekymringer angående sikkerheten til dette produktet, vennligst kontakt produsenten eller din lokale forhandler.

Takk for at du bidrar til en trygg og morsom skyteopplevelse!