

EZ AIM® 23 X35 SHOOTING GALLERY CORRUGATED TARGET & BACKER - ALLEN CO INC EZ AIM 23"X35" SHOOTING GALLERY CORRUGATED TARGET & BACKER

ALLEN CO INC. EZ AIM® 23"X35" SHOOTING GALLERY CORRUGATED TARGET & BACKER Experience the pinnacle of shooting target innovation and versatility with the EZ Aim® Shooting Gallery. Crafted from corrugated stock, this target is "Target-rich" containing 38 different targets on a backerboard, perfectly suited for your range sessions. This target allows the shooter to plink away at a large variety of targets, providing ample supply to keep the fun going. Provided in the pack are 20-shooting targets, each measuring 23 x 35-inches. Elevate your shooting experience today with the EZ Aim® Shooting Gallery Target & Backer. Discover precision, durability, and endless shooting entertainment like never before. FEATURES PLINKING SHOOTING TARGET: Each target is designed with 38 different targets on a backboard, tailored for plink shooting practice. STURDY HEAVY-DUTY TARGET: Rugged construction for durability that lasts. AMPLE SUPPLY: Provided in the pack are 20-shooting targets offering an ample supply for extended shooting practice. SHOOTING TARGET: Each target measures 23-inches long x 35-inches wide, providing a generous size for a comprehensive shooting experience. SPECS Material: Paper Targets Size: 23 Inch x 35 Inch Weight: 0.2 lb

NO IMAGE
AVAILABLE

Attributes

- Name: ALLEN CO INC EZ AIM 23"X35" SHOOTING GALLERY CORRUGATED TARGET & BACKER
- Manufacturer: ALLEN CO INC
- Product no.: 430119960
- Mfr. No.: 15734
- Style: Bullseye
- Target Size/Type: 23 x 35
- Type: Papers
- Delivery weight: 0.091kg
- Shipping height: 584mm
- Shipping width: 889mm
- Shipping length: 4mm
- UPC: 026509075912

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: EZ AIM® 23 X35 SHOOTING GALLERY CORRUGATED TARGET & BACKER Safety Instruction Guide](#)
- [Italiano: Guida alla Sicurezza del Prodotto per EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer](#)
- [Norsk: Sikkerhetsinstruksjoner for EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer](#)

EZ AIM® 23 X35 SHOOTING GALLERY CORRUGATED TARGET & BACKER Safety Instruction Guide

Introduction

Thank you for choosing the EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer. This guide provides essential safety instructions and guidelines to ensure a safe and enjoyable shooting experience. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure that all users are familiar with basic firearm safety rules.
- Always handle firearms with care and respect.
- Use the target only in designated shooting areas that are safe and appropriate.
- Keep the shooting area clear of unauthorized individuals, especially children.
- Regularly inspect the target for any signs of damage or wear before use.
- Follow all local laws and regulations regarding shooting and target practice.
- In case of any accidents or unsafe conditions, report them to the appropriate authorities immediately.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection while shooting.
- Ensure that the target is securely positioned and will not fall or move during use.
- Do not shoot at the target if it shows signs of damage, such as tears or punctures.
- Avoid using the target in adverse weather conditions, such as high winds or rain, which may affect stability and safety.
- Never attempt to modify or alter the target in any way.
- Ensure that the area behind the target is safe and clear of people, animals, and property.
- Use only appropriate ammunition that is suitable for the firearms being used.

Instructions for Installation and Usage

1. Location Selection

- Choose a safe and appropriate location for setting up the target, ensuring a clear shooting lane and safe backstop.

2. Target Setup

- Unpack the target and backer from the packaging.
- Position the backer securely on a flat surface or attach it to a stable stand.
- Ensure that the target is aligned properly on the backer for optimal shooting.

3. Target Use

- Take aim and shoot at the designated targets on the backer.
- After shooting, inspect the target for damage and replace it if necessary.

4. PostShooting Procedures

- Once shooting is complete, safely store all firearms and ammunition.

- Collect any spent cartridges and dispose of them properly.
- Remove the target and backer from the shooting area if no longer in use.

Disposal Instructions

- Dispose of the target and backer in accordance with local waste disposal regulations.
- If the target is damaged, ensure that it is disposed of in a manner that prevents any potential hazards to the environment or public safety.

Contact Information for Further Support

For any questions or concerns regarding the EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer, please refer to the product packaging or visit the manufacturer's website for further assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the EZ AIM® Shooting Gallery Target & Backer!

Guida alla Sicurezza del Prodotto per EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer

Introduzione

Grazie per aver scelto il bersaglio EZ AIM® 23"X35" Shooting Gallery Corrugated Target & Backer di ALLEN CO INC. Questa guida fornisce importanti informazioni sulla sicurezza per garantire un utilizzo sicuro e responsabile del prodotto. Si prega di leggere attentamente queste istruzioni prima dell'uso.

Linee Guida Generali sulla Sicurezza

- Assicurarsi che il bersaglio sia utilizzato solo in ambienti adatti e sicuri, lontano da persone e animali.
- Controllare regolarmente il bersaglio per eventuali segni di usura o danni.
- Utilizzare sempre dispositivi di protezione personale (DPI) come occhiali di sicurezza durante le sessioni di tiro.
- Non utilizzare il bersaglio in condizioni meteorologiche avverse, come pioggia o vento forte.
- Tenere i bersagli e i materiali di tiro lontano dalla portata dei bambini e degli animali domestici.

Precauzioni di Sicurezza Specifiche per l'Uso

- **Identificazione dei pericoli:** Il bersaglio è progettato per l'uso con proiettili di piccolo calibro. L'uso di munizioni inappropriate può causare danni e lesioni.
- **Uso corretto:** Utilizzare solo munizioni raccomandate per il bersaglio. Non utilizzare proiettili metallici o altri materiali che possano danneggiare il bersaglio.
- **Posizionamento:** Assicurarsi che il bersaglio sia posizionato su una superficie stabile e sicura. Non utilizzare il bersaglio in prossimità di strade, edifici o altre aree popolate.
- **Controllo postuso:** Dopo ogni sessione di tiro, controllare il bersaglio per eventuali danni e sostituirlo se necessario.

Istruzioni per l'Installazione e l'Uso

1. Installazione del bersaglio:

- Posizionare il bersaglio su un supporto stabile o appendere il bersaglio in modo sicuro.
- Assicurarsi che il bersaglio sia visibile e facilmente accessibile per il tiro.

2. Utilizzo del bersaglio:

- Prima di iniziare a tirare, assicurarsi che l'area circostante sia libera da persone e animali.
- Seguire sempre le tecniche di tiro sicure e le linee guida per l'uso delle armi da fuoco.
- Non colpire il bersaglio con oggetti diversi dalle munizioni appropriate.

Istruzioni per lo Smaltimento

- Smaltire il bersaglio in conformità con le normative locali sui rifiuti.
- Non bruciare il bersaglio in quanto potrebbe rilasciare sostanze tossiche.
- Se il bersaglio è danneggiato o usurato, smaltirlo in modo responsabile, evitando di lasciarlo in aree pubbliche o non autorizzate.

Informazioni di Contatto per Ulteriore Supporto

Per domande relative alla sicurezza o per segnalare prodotti non sicuri, contattare il rappresentante locale di ALLEN CO INC o visitare il sito ufficiale dell'azienda per ulteriori informazioni. Si prega di tenere a mente che è importante segnalare qualsiasi incidente o problema di sicurezza alle autorità competenti.

Grazie per aver scelto EZ AIM® per le vostre esigenze di tiro. La vostra sicurezza è la nostra priorità.

Sikkerhetsinstruksjoner for EZ AIM® 23 X35 Shooting Gallery Corrugated Target & Backer

Introduksjon

Takk for at du valgte EZ AIM® 23"X35" Shooting Gallery Corrugated Target & Backer fra ALLEN CO INC. Dette produktet er designet for å forbedre skyteferdighetene dine på en trygg og morsom måte. For å sikre en sikker og effektiv bruk, vennligst les og følg disse sikkerhetsinstruksjonene nøye.

Generelle sikkerhetsretningslinjer

- Sørg for at produktet brukes i et trygt miljø, borte fra mennesker og dyr.
- Kontroller produktet for skader før bruk. Bruk ikke hvis det er skadet.
- Oppbevar produktet utilgjengelig for barn uten tilsyn.
- Følg alltid produsentens bruksanvisninger for korrekt bruk.
- Rapportér eventuelle farlige produkter eller ulykker til de relevante myndighetene.

Spesifikke sikkerhetsforholdsregler for bruk

- **Alder:** Dette produktet er ikke egnet for barn under 12 år uten tilsyn av en voksen.
- **Skyteområde:** Bruk alltid målet i et sikkert skyteområde, som er tilpasset for skyting.
- **Beskyttelsesutstyr:** Bruk alltid passende beskyttelsesutstyr, inkludert øyevern og hørselvern, når du skyter.
- **Måltrening:** Sørg for at målet er plassert på en stabil overflate og i riktig høyde for din skytepraksis.
- **Ammoniakk:** Unngå å bruke ammoniakk eller andre sterke kjemikalier for rengjøring av målet.

Instruksjoner for installasjon og bruk

1. Installasjon:

- Plasser målet på en flat og stabil overflate.
- Sørg for at målet er sikkert festet og ikke kan velte.
- Kontroller at det er tilstrekkelig avstand til eventuelle hindringer eller personer.

2. Bruk:

- Velg et passende skytevåpen og ammunisjon for målet.
- Still deg i en trygg posisjon i forhold til målet.
- Fokuser på å treffe de ulike målene på bakplaten.
- Etter bruk, inspiser målet for skader og oppbevar det på et tørt og trygt sted.

Avfallsinstruksjoner

- Når målet er slitt eller ikke lenger er i brukbar stand, må det kastes i samsvar med lokale avfallsbestemmelser.
- Bølgepapp kan vanligvis resirkuleres; sjekk med lokale resirkuleringsprogrammer for detaljer.

Kontaktinformasjon for videre støtte

For ytterligere spørsmål eller sikkerhetsinformasjonsforespørsel, vennligst kontakt produsentens kundeservice.

Ved å følge disse retningslinjene, kan du sikre en trygg og morsom opplevelse med EZ AIM® 23"X35" Shooting Gallery Corrugated Target & Backer. Takk for at du prioriterer sikkerheten!