

Z AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER - ALLEN CO INC EZ AIM 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER

ALLEN CO INC. EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER Experience the pinnacle of shooting target innovation and versatility with the EZ Aim® Handgun Games Shooting Target & Backer. Crafted from corrugated stock, this target serves as both a durable shooting target and a reliable backerboard, perfectly suited for your range sessions. Unleash your shooting skills with not one, not two, but three exhilarating game options: engage in a thrilling game of tic-tac-toe, test your precision with darts, or take aim at the challenging bowling pin shoot. Provided in the pack is 1-shooting target and contains total of six distinctive target faces printed on a 23 x 35-inch cardboard, providing ample supply to keep the fun going. Elevate your shooting experience today with the EZ Aim® Corrugated Handgun Games Target & Backer. Discover precision, durability, and endless shooting entertainment like never before. FEATURES RANGE SHOOTING GAMES: Each target is designed with three exhilarating game options: tic-tac-toe, darts, & bowling offering an arcade-like entertainment at the range. STURDY HEAVY-DUTY TARGET: Rugged construction for durability that lasts. TIC-TAC-TOE (3 SURFACES): Enjoy the classic game on three different target areas. DART BOARD (2 SURFACES): Challenge your aim with two dart board designs. SHOOTING TARGET: Each target measures 23-inches wide x 35-inches tall, providing a generous size for a comprehensive shooting experience. SPECS Material: Paper Targets Size: 23 Inch x 35 Inch Weight: 0.2 lb

NO IMAGE
AVAILABLE

Attributes

- Name: ALLEN CO INC EZ AIM 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER
- Manufacturer: ALLEN CO INC
- Product no.: 430119964
- Mfr. No.: 15736
- Style: Bullseye
- Target Size/Type: 23 x 35
- Type: Papers
- Delivery weight: 0.091kg
- Shipping height: 584mm
- Shipping width: 889mm
- Shipping length: 4mm
- UPC: 026509075936

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for EZ Aim® 23"X35" Handgun Games Corrugated Target & Backer](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per il Bersaglio EZ AIM® 23"X35" HANDGUN GAMES](#)
- [Norsk: Bruksanvisning for sikkerhet EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER](#)

Safety Instruction Guide for EZ Aim® 23"X35" Handgun Games Corrugated Target & Backer

Introduction

Thank you for choosing the EZ Aim® 23"X35" Handgun Games Corrugated Target & Backer by Allen Co Inc. This guide provides important safety information and usage instructions to ensure a safe and enjoyable shooting experience. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure the target is used in a safe shooting environment, such as a designated shooting range.
- Always follow local laws and regulations regarding the use of firearms and shooting targets.
- Keep the target out of reach of children and unauthorized users.
- Regularly inspect the target for any signs of damage or wear before use.
- Do not use the target if it is damaged or compromised in any way.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when shooting.
- Ensure that the shooting area is clear of bystanders and that a safe backdrop is present.
- Do not shoot at the target from an unsafe distance; maintain a safe shooting distance as per your range's guidelines.
- Avoid using the target in adverse weather conditions that may affect its stability or integrity.
- Follow the instructions provided for each game option to prevent accidents during use.

Instructions for Installation and Usage

- To set up the target:
 1. Choose a stable and secure location for installation.
 2. Ensure the target is positioned at an appropriate height for shooting.
 3. Use a stand or backerboard if necessary to provide additional support.
- For game options:
 - **TicTacToe:** Use the designated areas on the target to play. Ensure all players understand the rules.
 - **Darts:** Follow the specific dartboard designs provided on the target. Use appropriate darts and ensure they are in good condition.
 - **Bowling Pin Shoot:** Set up bowling pins at the recommended distance and aim at the target accordingly.
- After use, carefully dismantle the target and dispose of it properly.

Disposal Instructions

- Dispose of the target in accordance with local waste disposal regulations.
- Recycle the cardboard material if possible, as it is made from paper.
- Ensure that any leftover materials, such as darts or other game pieces, are disposed of safely to avoid injury.

Contact Information for Further Support

For any questions or concerns regarding the EZ Aim® 23"X35" Handgun Games Corrugated Target & Backer, please refer to the contact information provided by the retailer or manufacturer.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the EZ Aim® target!

Guida alle Istruzioni di Sicurezza per il Bersaglio EZ AIM® 23"X35" HANDGUN GAMES

Introduzione

Grazie per aver scelto il bersaglio e supporto EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER di ALLEN CO INC. Questa guida fornisce informazioni importanti per garantire un uso sicuro e responsabile del prodotto, seguendo le linee guida stabilite dal Regolamento Generale sulla Sicurezza dei Prodotti dell'UE (GPSR).

Linee Guida Generali di Sicurezza

- Assicurati che il bersaglio sia utilizzato solo in ambienti adeguati e sicuri, lontano da persone non coinvolte nelle sessioni di tiro.
- Controlla regolarmente il bersaglio per eventuali segni di usura o danni. Non utilizzare il bersaglio se presenta segni di deterioramento.
- Mantieni il bersaglio in un luogo asciutto e pulito per preservarne la qualità e la durata.
- Segui sempre le istruzioni del produttore per un uso corretto e sicuro.

Precauzioni di Sicurezza Specifiche per l'Uso

- Utilizza il bersaglio solo con armi da fuoco per cui è progettato.
- Non utilizzare il bersaglio in condizioni meteorologiche avverse, come pioggia o vento forte, che potrebbero compromettere la stabilità del bersaglio.
- Assicurati che il bersaglio sia posizionato su una superficie stabile e sicura.
- Non lasciare mai il bersaglio incustodito durante le sessioni di tiro.
- Non tentare di modificare o riparare il bersaglio in modo non autorizzato.

Istruzioni per l'Installazione e l'Uso

1. Preparazione dell'Area di Tiro

- Seleziona un'area di tiro sicura e appropriata, lontana da persone e animali.
- Assicurati che l'area sia ben illuminata e priva di ostacoli.

2. Installazione del Bersaglio

- Posiziona il bersaglio su un supporto stabile o fissalo a una superficie adeguata.
- Verifica che il bersaglio sia ben fissato e non possa cadere o spostarsi durante l'uso.

3. Utilizzo del Bersaglio

- Prima di iniziare, assicurati che tutti i partecipanti comprendano le regole di sicurezza del tiro.
- Utilizza il bersaglio secondo le diverse opzioni di gioco disponibili: tictactoe, freccette e bowling.
- Dopo aver completato la sessione di tiro, assicurati che tutte le armi siano scariche e sicure.

Istruzioni per lo Smaltimento

- Quando il bersaglio non è più utilizzabile, smaltiscilo in modo responsabile.
- Segui le normative locali per il riciclaggio della carta e dei materiali di imballaggio.
- Non abbandonare il bersaglio in luoghi pubblici o non autorizzati.

Informazioni di Contatto per Ulteriore Supporto

Per ulteriori informazioni sulla sicurezza del prodotto, ti invitiamo a contattare il servizio clienti di ALLEN CO INC. Assicurati di avere il numero di modello del prodotto a portata di mano per ricevere assistenza specifica.

Grazie per aver scelto il bersaglio EZ AIM® 23"X35" HANDGUN GAMES. Segui queste linee guida per garantire un'esperienza di tiro sicura e divertente!

Bruksanvisning for sikkerhet EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER

Introduksjon

Takk for at du har valgt EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER. Denne produktmanualen inneholder viktig informasjon om sikker bruk, installasjon, og avhending av produktet. Vennligst les nøye gjennom alle instruksjoner for å sikre en trygg og morsom opplevelse.

Generelle sikkerhetsretningslinjer

- Sørg for at produktet brukes i samsvar med alle lokale lover og forskrifter angående skyting.
- Hold produktet utilgjengelig for barn og sårbare grupper når det ikke er i bruk.
- Bruk alltid passende sikkerhetsutstyr, inkludert øye og hørselsvern, når du bruker målet.
- Kontroller produktet for skader før bruk. Hvis det er skadet, ikke bruk det og kontakt for videre instruksjoner.
- Følg alltid produsentens anbefalinger for bruk og vedlikehold.

Spesifikke sikkerhetsforholdsregler for bruk

- Bruk målet kun i et sikkert skyteområde som er designet for skyting.
- Unngå å bruke målet i nærheten av mennesker eller dyr.
- Sørg for at det er tilstrekkelig avstand mellom deg og målet for å unngå skader fra avfyrte prosjektiler.
- Unngå å bruke målet i våte eller fuktige forhold, da dette kan påvirke materialets holdbarhet.
- Vær oppmerksom på at målet er laget av bølgepapp og kan bli skadet av kraftige treff eller værforhold.

Instruksjoner for installasjon og bruk

1. Installasjon:

- Plasser målet på en stabil overflate som er egnet for skyting.
- Sørg for at målet står oppreist og er sikret mot vind eller annen påvirkning som kan velte det.
- Hvis mulig, fest målet til bakken for ekstra stabilitet.

2. Bruk:

- Start med å velge hvilket spillalternativ du ønsker å spille: tictactoe, dart eller bowling.
- Følg de spesifikke reglene for hvert spill for å maksimere moro og sikkerhet.
- Etter hver økt, inspiser målet for eventuelle skader og reparer eller bytt det ut om nødvendig.

Avhending av produktet

- Når målet ikke lenger er i bruk, sørg for å avhende det på en miljøvennlig måte.
- Bølgepapp kan vanligvis resirkuleres. Sjekk lokale retningslinjer for resirkulering.
- Unngå å brenne produktet, da dette kan frigjøre skadelige stoffer.

Kontaktinformasjon for videre støtte

For spørsmål om sikkerhet eller produktinformasjon, vennligst kontakt produsenten direkte via de tilgjengelige kanalene.

Takk for at du følger disse retningslinjene for sikkerhet. Vi ønsker deg en trygg og underholdende opplevelse med EZ AIM® 23"X35" HANDGUN GAMES CORRUGATED TARGET & BACKER!